

1. Open the capture file and note the total number of packets.
 2. From Statistics → Protocol Hierarchy, identify the top 3 protocols by packet count.
 3. Apply filter `ip.src == 10.207.231.112` How many packets match?
 4. Apply filter `http`. Identify one GET request. Write the Host + URI.
 5. Apply filter `dns`. List any two domain names queried.
 6. Apply filter `tcp.port == 443`. How many HTTPS packets were captured?
 7. Apply filter `arp`. Write one Request and its Reply (with MACs).
 8. Find a TCP Reset (RST) packet. Write source + destination IPs.
 9. Add a new column Delta time displayed. Write delay between 1st and 2nd HTTP packet.
 10. Save only HTTP packets into a new file `set1_http.pcapng`.
-
1. From Statistics → Protocol Hierarchy, write the percentage of TCP, UDP, ICMP.
 2. Apply filter `arp`. Find one ARP Request + Reply.
 3. Apply filter `icmp`. Identify one Echo Request and its Reply (with sequence no.).
 4. Select a TCP conversation → Follow TCP Stream. Write a short note on the contents.
 5. From Statistics → Conversations, find the top 2 IP pairs.
 6. Apply filter `tcp.flags.syn == 1`. Write first SYN packet number.
 7. Apply filter `dns`. Note one query + its resolved IP.
 8. Use Edit → Coloring Rules to highlight UDP traffic. Note first highlighted packet.
 9. Add a column for `tcp.stream` index. Write values for the first 3 TCP connections.
 10. Export the first 50 packets into a plain text file. Note file size.
-
1. Apply filter `tcp && ip.src == 64.233.170.188`. Count packets.
 2. Apply filter `ip.src[0:1]==172`. Count packets.
 3. Apply filter `dns`. Find one query + response IP.
 4. Find one ICMP Request and Reply. Write RTT (Round Trip Time).
 5. Use File → Export Objects → HTTP. Export one file. Note filename + size.
 6. Apply filter `tls`. Write the TLS version observed.
 7. Apply filter `tcp.analysis.retransmission`. Count retransmissions.
 8. Find the largest packet in the capture. Write size + protocol.
 9. Apply filter `http.request`. Write first User-Agent string.
 10. From Statistics → Conversations, note the conversation with highest bytes exchanged.
-
1. Count the total number of packets captured.

2. From Protocol Hierarchy, identify top 3 protocols by percentage.
 3. Apply filter `http.request.method == "POST"`. Write Host and Content-Type.
 4. Apply filter `arp`. Write one Request and Reply (with MACs).
 5. Find one TCP Reset (RST) packet. Write IP + ports.
 6. Apply filter `tls`. Write the TLS version observed.
 7. Export packet dissections of the first 25 packets into plain text. Note file size.
 8. Find the first HTTP response code (200/404/etc.). Write a packet number.
 9. From Statistics → Endpoints, identify top 2 IPs by traffic.
 10. Add a Coloring Rule for TCP SYN packets. Note first highlighted packet.
1. Change Time Format → Seconds Since Beginning. Write arrival time for the first 3 packets.
 2. Apply filter `udp`. Identify 2 source ports + 2 destination ports.
 3. Apply filter `icmp`. Find a Destination Unreachable message. Write packet no.
 4. Apply filter `(ip.src == 10.0.0.2 && tcp) || dns`. Count packets.
 5. Apply filter `http`. Write one GET request URI.
 6. From Conversations, identify the longest TCP conversation.
 7. Apply filter `tcp.flags.syn == 1`. Write first SYN packet number.
 8. Export one HTTP object. Write filename + size.
 9. Apply filter `dns`. Write one query + resolved IP.
 10. Add Delta Time Displayed column. Write delay between two ICMP packets.
1. Count the total number of packets captured.
 2. Apply filter `http`. Follow one HTTP stream. Write a short note on the exchange.
 3. Apply filter `http.request.method == "POST"`. Write Host and Content-Type.
 4. Apply filter `arp`. Write one Request and Reply with MAC Addresses.
 5. Identify SYN, SYN-ACK, ACK packet numbers + sequence numbers.
 6. Use Find Packet → Regex. Search for "User-Agent". Note packet number.
 7. Apply filter `dns`. Write one query + resolved IP.
 8. Apply filter `ip.addr in {192.168.1.10 192.168.1.15}`. Count packets.
 9. From Conversations, identify the top 2 IP pairs.
 10. Export one HTTP object. Write filename + size.